



## CTI Taper Bushes

### Metric

#### Bush Standard Bore Sizes

[mm]

1008	10	11	12	14	16	18	19	20	22	24	25								
1108	10	11	12	14	16	18	19	20	22	24	25	28							
1210	11	12	14	16	18	19	20	22	24	25	28	30	32						
1215	11	12	14	16	18	19	20	22	24	25	28	30	32						
1610	14	16	18	19	20	22	24	25	28	30	32	35	38	40	42				
1615	14	16	18	19	20	22	24	25	28	30	32	35	38	40	42				
2012	14	16	18	19	20	22	24	25	28	30	32	35	38	40	42	45	48	50	
2017	24	30	32	38	40														
2517	16	18	19	20	22	24	25	28	30	32	35	38	40	42	45	48	50	55	60
2525	19	20	22	24	25	28	30	32	35	38	40	42	45	48	50	55	60		
3020	25	28	30	32	35	38	40	42	45	48	50	55	60	65	70				
3030	32	35	38	40	42	45	48	50	55	60	65	70	75						
3525	50	60	65	80															
3535	38	40	42	45	48	50	55	60	65	70	75	80	85	90					
4040	40	42	45	48	50	55	60	65	70	75	80	85	90	95	100				
4545	55	60	65	70	75	80	85	90	95	100	105	110							
5050	75	80	85	90	95	100	105	110	115	120	125								

### Imperial

#### Bush Standard Bore Sizes

[in]

1008	1/2	5/8	3/4	7/8	1														
1108	1/2	5/8	3/4	7/8	1	1 1/8													
1210	1/2	5/8	3/4	7/8	1	1 1/8	1 1/4												
1215	1/2	5/8	3/4	7/8	1	1 1/8	1 1/4												
1610	1/2	5/8	3/4	7/8	1	1 1/8	1 1/4	1 3/8	1 1/2	1 5/8									
1615	1/2	5/8	3/4	7/8	1	1 1/8	1 1/4	1 3/8	1 1/2	1 5/8									
2012	1/2	5/8	3/4	7/8	1	1 1/8	1 1/4	1 3/8	1 1/2	1 5/8	1 3/4	2							
2517	1/2	5/8	3/4	7/8	1	1 1/8	1 1/4	1 3/8	1 1/2	1 5/8	1 3/4	2	2 1/8	2 1/4	2 3/8	2 1/2			
2525	3/4	7/8	1	1 1/8	1 1/4	1 3/8	1 1/2	1 5/8	1 3/4	2	2 1/8	2 1/4	2 3/8	2 1/2					
3020	1 1/8	1 1/4	1 3/8	1 1/2	1 5/8	1 3/4	1 7/8	2	2 1/8	2 1/4	2 3/8	2 1/2	2 5/8	2 3/4	2 7/8	3			
3030	1	1 1/8	1 1/4	1 3/8	1 1/2	1 5/8	1 3/4	1 7/8	2	2 1/8	2 3/8	2 1/2	2 5/8	2 3/4	2 7/8	3			
3535	1 1/4	1 3/8	1 1/2	1 5/8	1 3/4	2	2 1/8	2 1/4	2 3/8	2 1/2	2 3/4	3	3 1/4	3 3/8	3 1/2				
4040	1 1/2	1 5/8	1 3/4	2	2 1/8	2 1/4	2 3/8	2 1/2	2 3/4	3	3 1/4	3 3/8	3 1/2	3 5/8	3 3/4	3 7/8	4		
4545	2	2 1/8	2 1/4	2 3/8	2 1/2	2 3/4	3	3 1/4	3 3/8	3 1/2	3 5/8	3 3/4	3 7/8	4	4 1/8	4 1/4	4 3/8	4 1/2	
5050	3 7/8	4	4 1/8	4 1/4	4 3/8	4 1/2	4 7/8	5											

### Taper bush part numbers

When placing an order please specify the product code which is composed in accordance with the following examples:

T B	---	2 0 1 2	---	M	---	0 4 0
Prefix	Bush Size	Unit	Bore			
Bore:						
T B	---	2 0 1 2	---	B	---	1.500
Prefix	Bush Size	Unit	Bore			

**Prefix:** TB=Taper Bush BushSize:1008to5050  
**Unit:** M=Metric. B=Imperial  
**Metric:** (Bore in mm padded to 3 digits)  
**Imperial:** (Bore in inches to 3 decimal places)

All the dimensions in millimetres unless otherwise stated.

CTI do not accepts any liability for any inaccuracies or damage caused.